


The feed roll


It should not be necessary to replace the feed roll but you need to keep it reasonably free from dirt. The roll is best cleaned with Isopropyl Alcohol, but normal Ethanol Alcohol is also OK. Avoid strong detergents as this can destroy the roll!

REPLACING THE FEED ROLL

1. Remove the cover (see separate instruction).
2. Remove the screw on the inner panel as shown below.



3. Remove the screw on the roll as shown below



4. You can now pull back the motor and take out the roller through the inner panel.
5. Proceed in the reversed order to mount a new roller.